


hidden key



RB RADIO BUTTONS 4CH

DICHIARAZIONE DI CONFORMITÀ / DECLARATION OF CONFORMITY / DÉCLARATION DE CONFORMITÉ
KONFORMITÄTSERKLÄRUNG / DECLARACION DE CONFORMIDAD / DECLARAÇÃO DE CONFORMIDADE

BFT S.p.a

Indirizzo / Address / Adresse / Adresse / Dirección / Endereço.

Via Lago di Vico 44
36015 - Schio
VICENZA - ITALY

- Dichiaro sotto la propria responsabilità che il prodotto: / Declares under its own responsibility that the following product: / Déclare sous sa propre responsabilité que le produit: / Erkläre auf eigene Verantwortung, daß das Produkt: / Declaro bajo su propia responsabilidad, que el producto: / Declaro, sob a sua responsabilidade, que o produto:

Sistema radiocomando / Radio control system / Système radiocommande / Fernsteuersystem / Sistema de radiocomando
/ Sistema radiocomando

RB

- È conforme ai requisiti essenziali di sicurezza delle Direttive. / It complies with the main safety requirements of the following Directives: / Est conforme aux exigences essentielles de sécurité des Directives: / Es entspricht den grundlegenden Sicherheitsbedingungen der Direktiven: / Es conforme a los requisitos esenciales de seguridad de las Directivas: / Esta conforme aos requisitos essenciais de segurança das Directivas:

APPARECCHIATURE RADIO / RADIO SETS / INSTALLATIONS RADIO / RÁDIOAPARÁTE / RADIOEQUIPOS /
RADIOAPARELHOS 99/5/CEE (CTSI EN 301 489-3 (2000) + ETSI EN 301 489-1 (2000), ETSI EN 300 220-3
(2000), EN60950 + EN6037*) (e modifiche successive / and subsequent amendments / et modifications
successives / und ihren nachfolgende Änderungen / e modificações sucessivas / y modificaciones sucesivas).

SCHIO, 13/02/2008

Il Rappresentante Legale / The legal Representative
Le Représentant légal / Der gesetzliche Vertreter
El Representante Legal / O Representante legal


(GIANCARLO BONOLLO)

1) TECHNICAL SPECIFICATIOS

Frequency:.....433.92MHz
battery:.....12V
Range: 40 / 60 m
mod:.....RB
Protection:.....IP 4X

2) MAINTENANCE

Any reduction in the transmitter capacity may be due to the batteries getting flat. If the LED of the transmitter flashes when pressing T1, it means that the batteries are flat and must be replaced. Instructions are subject to change without notice. The terminals of the batteries should not be short-circuited or touched with the hands.

<https://aros.kz>

**AZIENDA CON SISTEMA DI GESTIONE
INTEGRATO CERTIFICATO DA DNV
= UNI EN ISO 9001:2000 =
UNI EN ISO 14001:2004**

Via Lago di Vico 44
36015 Schio (VI) - Italy
Tel. +39 0445 69 65 11
Fax. +39 0445 69 65 22
www.bft.it
e-mail: info@bft.it



