

CONFORMITY DECLARATION

Hereby, Nice S.p.A., declares that this FLO1, FLO2, FLO4, FLO2R-M, FLO4R-M, FLO1R-S, FLO2R-S, FLO4R-S, FLO1R-SC, FLO2R-SC, FLO4R-SC is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at www.niceforyou.com

IMPORTANT: FLO1R-S/U, FLO2R-S/U, FLO4R-S/U (code for USA: FCC ID - PML433FRS; code for Canada: IC - 6140A-433FRS), FLO1R-S/A, FLO2R-S/A, FLO4R-S/A (code for USA: FCC ID - PML433FRA), to read the following declaration.

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications made to this device without the express permission of the manufacturer may void the user's authority to operate this device.

TECHNICAL CHARACTERISTICS

■ **Frequency:** 433.92 MHz (± 100 kHz)
 ■ **Power supply:** 12V~; with 23A type battery
 ■ **Battery life:** approximately 1 year (with 10 transmissions per day) ■
 ■ **Range:** approximately 150 m outside and up to 35 m inside ■ **Radio coding:** Flo = 12 bit fixed; FloR = 52 bit rolling code ■ **Operating temperature:**

PRODUCT DESCRIPTION

The transmitter that you have purchased belongs to the **FLO** line of Nice S.p.A. The transmitters of this line are exclusively destined for the control of automation systems such as opening devices for doors, gates and roller shutters etc., **other uses are considered improper!** This line is made up of two product types: "**Flo**" with programmable codes and "**FloR**" with variable codes (rolling-code). Each type has 1, 2 and 4 channel models and each model must be associated to a specific Receiver in order to function (see the Nice S.p.A. product catalogue for compatibility). In particular, the FLO2R-M and FLO4R-M models can also function with the Nice "MOM" and "MOMB" proximity reader.

"FLO" LINE MODELS

• **EU and CH versions:** FLO1, FLO2, FLO4, FLO2R-M, FLO4R-M, FLO1R-S, FLO2R-S, FLO4R-S, FLO1R-SC, FLO2R-SC, FLO4R-SC • **USA (FCC Part 15) and Canadian (RSS-210) versions:** FLO1R-S/A, FLO2R-S/A, FLO4R-S/A.

PROGRAMMING

First check that the transmitter is operating by pressing one of its keys and check that the Led flashes at the same time (= transmission performed).

• The "**Flo**" type transmitters are programmed by setting the same On and Off combination that is on the receiver with the DIP-switch (**Fig. C**).

• The "**Flo-R**" type receivers can be programmed in different ways based on the possibilities offered by the associated receiver. Therefore, program your transmitter by carefully following the instructions contained in your Receiver manual. This manual is also available on the www.niceforyou.com web site.

REPLACEMENT OF THE BATTERY

The range of the transmitter and the brightness of the Led are reduced when the battery is flat. The normal function is re-established when the flat battery is replaced, making sure that the poles are respected (**Fig. A, B**).


Nice

FLO Transmitter

CE 0682

- EN** - Instructions and warnings for installation and use
IT - Istruzioni ed avvertenze per l'installazione e l'uso
FR - Instructions et avertissements pour l'installation et l'utilisation
ES - Instrucciones y advertencias para la instalación y el uso
DE - Installierungs- und Gebrauchsanleitungen und Hinweise
PL - Instrukcje i ostrzeżenia do instalacji i użytkowania
NL - Aanwijzingen en aanbevelingen voor installatie en gebruik

<https://aros.kz>



Nice S.p.A.
 Via Pezza Alta, 13
 31046 Oderzo TV Italy
info@niceforyou.com

www.niceforyou.com

Nice